Big Dog Power Driver for Control4

Compatibility

This driver is compatible with the following Big Dog Power models:

- PR-R13PI
- PR-V7PI
- PR-W3PI
- PR-S1PI

Features

- Ability to control outlets (On, Off, or Cycle) from Properties tab or Keypad bindings
- Ability to activate Up or Down Sequencing from the Actions tab
- Custom programming options to control individual outlets or sequence
- Events based on controllable outlet state changes
- Device variables for the status of each controllable outlet

Steps to Install

1. Install driver in project
2. In Properties add the correct IP address for the Big Dog Power device.
3. Attach bindings or use custom programming to control individual outlets

   Note: PDU firmware 2.0 and later will need default credentials: User: *admin*, Password: *admin*

The driver will create relay bindings for controllable outlets once communication with the PDU has been established. Add bindings in the Connections tab or custom programming to control the PDU.

Troubleshooting

Clearing the IP from the driver will reset all internal settings.
